




JOT Pencil



User Manual

Thank you for purchasing this UltraProlink product. Please read these instructions completely to get the maximum out of this product.

Product Details



Salient Features

- Capacitive Stylus with Dual Modes - iPad® & Universal
- Palm-Rejection function for iPad®
- Aluminium Alloy body with strong magnetic hold
- Replaceable Nibs x 2
- 5 mins Auto-Off
- No Delay or Offset

Technical Specifications

Model : UM1224WHT

Dimensions : 9mm x 167.5mm x 1.5mm

Nib Dia : 1.5mm

Weight : 13.1g

Battery : 130mAh

Charging Port : Type-C USB

Charging Input : DC 5V-0.2A

Charging time : approx 30min

Auto Power Off : 5 min

Use time : 8-10 hours on full charge

Standby Time : 90 days

Palm-Rejection : Yes-iPad® Mode Only

Compatibility

In Universal mode all devices with capacitive screens will work

Compatible iPad® Models as listed below

iPad® 2018 (6th gen): A1893/A1954

iPad® 2019 (7th gen): A2197/A2200/A2198

iPad® 2020 (8th gen): A2270/A2428/A2429/A2430

iPad® 2021 (9th gen): A2602/A2604/A2603/A2605

iPad® 2022 (10th gen): A2696/A2757/A2777/A3162

iPad® 2025 (A16): A3354/A3355/A3356

iPad® mini 2019 (5th gen): A2133/A2124/A2126/A2125

iPad® mini 2021 (6th gen): A2567/A2568/A2569

iPad® mini 2024 (A17 Pro): A2993/A2995/A2996

iPad® Air 2019 (3rd gen): A2152/A2123/A2153/A2154

iPad® Air 2020 (4th gen): A2316/A2324/A2325/A2072

iPad® Air 2022 (5th gen): A2588/A2589/A2591

iPad® Air 2024 11" (M2): A2902/A2903/A2904

iPad® Air 2025 11" (M3): A3266/A3267/A3270

iPad® Air 2024 13" (M2): A2898/A2899/A2900

iPad® Air 2025 13" (M3): A3268/A3269/A3271

iPad® Pro 2018 11" : A1980/A2013/A1934

iPad® Pro 2020 11" (2nd gen): A2228/A2608/A2230/A2231

iPad® Pro 2021 11" (3rd gen): A2377/A2459/A2301/A2460

iPad® Pro 2022 11" (4th gen): A2759/A2761/A2435/A2762

iPad® Pro 2024 11" (M4): A2836/A2837/A3006

iPad® Pro 2018 12.9" (3rd gen): A1876/A2014/A1895/A1983

iPad® Pro 2020 12.9" (4th gen): A2229/A2069/A2232/A2233

iPad® Pro 2021 12.9" (5th gen): A2378/A2461/A2379/A2462


iPad® Pro 2022 12.9" (6th gen): A2436/A2437/A2764/A2766

iPad® Pro 2024 13" (M4): A2925/A2926/A3007

Please confirm the above models on the back of your iPad®


Setting Up for iPad® Use

1. Works on iPad® 2018 & later
2. If using an original pencil, turn off the connection from settings.
3. Open Settings → Apple Pencil → only draw with Apple Pencil(OFF).
4. Go to Settings → Bluetooth and remove the connection of the original Apple Pencil.



How to Use Dual Mode

1. Tap the sensor switch on the top to turn it on-the LED turns green, and now the stylus is in iPad® dedicated mode. At this time, it can be used on the iPad® with Palm-rejection mode.



2. Tap the switch again, the LED turns blue, and the stylus is now in Universal mode. At this time, it can be used on any capacitive screen device. Touch the switch again to turn off the capacitive stylus.

The flat surface of the stylus is magnetic & it can be attached to the iPad® like the original pencil (limited to iPad®s / & Other Tablets which allow magnetic adsorption)



Charging instructions

1. Insert the Type-C charging cable into the charging port of the stylus, and the LED turns red to indicate normal charging. Time to full charge is 30 mins.


2. Once fully charged the LED turns off.

3. Low Battery Alert : LED Flashes on-off

4. Stylus can be recharged using a low power source like laptop USB port, power bank or low power wall charger(5W-10W).

DO NOT USE A HIGH POWER CHARGER TO CHARGE THIS STYLUS AS IT MAY DAMAGE THE BATTERY.

Nib replacement



This stylus comes with easy to replace nibs. Simply unscrew the nib at the bottom, detach & screw in the new one

Scan this QR code to register your purchase & Activate Warranty



Date of Purchase:

Seller Stamp & Sign:

Warranty Disclaimer: This product comes with a twelve months repair warranty against any manufacturing defects. There is no warranty on battery lifecycles. The Battery is not replaceable under warranty unless the product is found Dead on Arrival. Warranty will be null & void if the unit has been found to have been tampered with, with water seepage or misused in any way. Breakage & usual wear & tear of the nib are not covered under warranty or repair.

Please write in to us at
support@utraprlink.com or call on
+91-9312229953 / Mon-Sat / 10:00am – 6:00pm